

**CONTROLLA LA LISTA DEGLI ADATTATORI PER SAPERE SE FUNZIONA
ANCHE IL TUO CELLULARE**

NOKIA 1

3100 / 3108 / 3120 / 3200 / 3220 / 3230 / 3300 / 5100 / 5140 / 6020 / 6021 / 6100 /
6108 / 6170 / 6200 / 6220 / 6230 / 6230i / 6260 / 6610 / 6610i / 6620 / 6630 / 6650 /
6670 / 6680 / 6681 / 6800 / 6810 / 6820 / 6822 / 7200 / 7210 / 7250 / 7250i / 7260 /
7600 / 7610 / 7700 / 7710 / 9300 / 9500 / 9500c

NOKIA 2

1100 / 1220 / 1221 / 1260 / 1261 / 2100 / 2300 / 2600 / 2650 / 3210 / 3310 / 3320 /
3330 / 3360 / 3361 / 3390 / 3395 / 3410 / 3510 / 3510i / 3520 / 3560 / 3590 / 3595 /
3600 / 3650 / 3660 / 5210 / 5510 / 6500 / 6510 / 6590 / 6590i / 6600 / 7280 / 7650 /
8210 / 8250 / 8260 / 8265 / 8270 / 8290 / 8310 / 8390 / 8850 / 8855 / 8860 / 8890 /
8910 / 8910i

NOKIA 3

5100 series / 5110 / 5120 / 514 / 5165 / 6110 / 6300 series / 640 / 650 / 7100series /
3285 / 6120 / 6150 / 6160 / 6161 / 6165 / 6185i / 6190 / 6210 / 6310 / 6310i / 7110

SONY ERICSSON 1

P802 / P900 / P908 / P910 / R20 / R28 / R300 / R300LX / R300z / R310 / R320 /
R328 / R380 / R380e / R380s / R520 / R2320 / S700i / T20 / T28 / T29 / T39 / T39m /
T65 / T66 / T68 / T68i / T100 / T102 / T200 / T206 / T226 / T230 / T300 T306 / T310 /
T312 / T316 / T600 / T610 / T612 / T616 / T618 / T630 / V800 / Z200 / Z208 / Z500 /
Z600 / Z608 / Z1010

SONY ERICSSON 2

K750i / P990i / W550i / W800i / W900i / Z520

SAMSUNG 1

A800 / C100 / D410 / E100 / E108 / E400 / E700 / E708 / E715 / N275 / N375 / N600 /
N620 / N628 / P400 / S100 / S108 / S500 / S508 / S800 / T100 / T108 / T400 / T408 /
T500 / T508 / V200 / V208 / X100 / X450 / X600

SAMSUNG 2

A288 / N100 / N188 / N200 / N288 / R220 / R225 / S600 / S2100 / S2400

SIEMENS 1

A55 / A56 / A57 / A60 / A65 / C55 / C56 / C60 / C62 / C65 / CF52 / CF62 / CFX65 /
CV65 / CX65 / CX70 / CX70EMoty M55 / M65 / MC60 / MCT62 / S55 / S56 / S57 /
S65 / SF65 / SL55 / SL56 / SX1 / 2128

SIEMENS 2

A40 / C25 / C35 / C45 / M46 / S25 / S35 / S45 / SC45 / SL42 / SL45 / 1128 / 6688

Per questi modelli NON SERVE L'ADATTATORE

**BLACKBERRY / SANYO / LG / MOTOROLA (ESCLUSO RAZR V3 – CHIEDI
INFORMAZIONI) / PANASONIC / SHARP / TREO**

